

Attention: Smoothing with hands to make sure the backrest is flat.