



HULALA

HOME



ITEM NO. SCRB1533

100 LBS

Thank You For Choosing Our Furniture

▀ If you have any questions or concerns,
don't hesitate to reach out to us. ▴

Call us: +1(833)324-2464
Email: hello@hulalahome.com

NOTE:






This brochure contains
IMPORTANT safety info.
Please read and keep it
for future reference.

MAINTAINANCE AND WARNINGS



Before You Start

Please follow the steps below:




-  Check the packaging for any damage, deformation, or water stains. If there is significant damage, please contact us promptly.
-  Open the packaging and confirm that the panels, hardware, screws, etc are complete.
-  Please read the installation instructions carefully to understand the installation steps and precautions to ensure proper installation.
-  Clean the installation area in advance and ensure the ground is level and there is enough space to avoid damaging the furniture or making installation difficult.
-  Lay a protective mat on the ground to prevent scratching the floor during installation.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.





Precautions

-  This product for indoor use only. Do not expose it to outdoor elements or high-humidity environments.
-  Keep the product away from high heat or open flames to prevent fire hazards.
-  Do not allow children to climb on the product to prevent personal injury caused by tipping



Safety Warnings


-  If you notice any loose or damaged parts, stop using the product immediately and contact customer service.
-  Do not attempt to disassemble or replace any components yourself, as this may affect the stability and safety of the product.

Daily Maintenance









- Regularly clean the surface of the sofa with a soft cloth to prevent dust accumulation.

Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners
- Avoid exposing furniture to humid environments for extended periods to prevent swelling or deformation of the boards. Use a dehumidifier or desiccant during humid weather.
- Avoid direct contact of furniture with water. If water is accidentally spilled, wipe it dry immediately.
- Avoid placing excessively heavy objects on the furniture: ensure the weight is within a reasonable load-bearing range.
- Avoid using sharp or rough items on the furniture surface to prevent scratches, Handle items gently when moving them

Explosive view



Parts list

<p>A</p>  <p>x1</p>	<p>B</p>  <p>x1</p>
<p>C</p>  <p>x1</p>	<p>D</p>  <p>x1</p>
<p>F</p>  <p>x1</p>	<p>G</p>  <p>x2</p>
<p>H</p>  <p>x1</p>	<p>J</p>  <p>x1</p>




Installation:
30minutes.



Two Person


Parts list

K




x1

N















x2

P












x2

Hardware List

<p>1</p>  <p>10+1</p>	<p>2</p>  <p>x10+1</p> <p>D15x12mm</p>	<p>3</p>  <p>x12</p> <p>D8x30mm</p>
<p>4</p>  <p>x2</p>	<p>5</p>  <p>x4</p> <p>D6x35mm</p>	<p>6</p>  <p>x12+1</p> <p>D3.5x14mm</p>
<p>7</p>  <p>x2</p> <p>D4x30mm</p>	<p>8</p>  <p>x8</p>	<p>9</p>  <p>x10+1</p>
<p>10</p>  <p>x4</p> <p>D7x40mm</p>	<p>11</p>  <p>x4</p>	<p>12</p>  <p>x4</p> <p>Large Bend</p>



Hardware List




<div>13</div> <div></div> <div>x6</div> <div>D7x70mm</div>	<div>14</div> <div></div> <div>x4</div> <div></div>	<div>15</div> <div></div> <div>x4</div> <div>D4x30mm</div>
<div>16</div> <div></div> <div>x4</div> <div></div>	<div>17</div> <div></div> <div>x2</div> <div></div>	<div>18</div> <div></div> <div>x4</div> <div>D3x14mm</div>
<div>19</div> <div></div> <div>x1</div> <div></div>	<div>20</div> <div></div> <div>x1</div> <div></div>	<div>21</div> <div></div> <div>x24+2</div> <div>D4x16mm</div>

Step 1

Prepare for part A




1. Tighten the bolt #1 into the corresponding hole of A with screwdriver #19
2. Align the holes in part A, insert wooden dowel #3 by hand






19	x1	3	x4	1	x8
					
		D8x30mm		M6x35mm	

Step 2

Use screws #18 to attach part #4 with screwdriver #19 as picture shown




18	x4	4	x2	19	x1
					
D3x14mm					




Step 3

1. Connect part C&H & D with part A, insert cam bolt #2 into the corresponding holes of part C&H& D.

then tighten the cam bolt #2 with screwdriver #19


2. Cover the cam lock #2 with sticker #9



2	x8	9	x8	19	x1
					
D15x12mm					


Step 4




1. Slide in part G into the groove in part C, H and H, D make sure they are also in groove
2. Please make sure that the panels which stick "BACK" are towards wall



Step 5


- 1.Align the holes in part B, insert wooden dowel #3 by hand
- 2.Use bolt #5 to attach part P to part B with the Allen key #20







20	x1	5	x4	3	x4
					
		D6x35mm		D8x30mm	

Step 6

1. Use #10 to attach part B to part N with Allen key #20
2. Tighten the bolt #1 into the corresponding hole of B with screwdriver #19










1	x2	19	x1	20	x1	10	x4
							
D6x35mm						D7x40mm	

Step 7

Connect the prepared parts together


- 1.Align the holes in part C&D, insert wooden dowel #3 by hand
- 2.Screw the bolt #13 tight with Allen key #20
- 3.Insert cam bolt #2 into the corresponding holes of part G.
then tighten the cam bolt #2 with screwdriver #19
4. Cover the cam lock #2 with sticker #9






2	x2	9	x2	19	x1	3	x4	13	x6	20	x1
											
D15x12mm						D8x30mm		D7x70mm			

Step 8


1. Insert hardware #8 into part G as show
- 2.Screw in screw #6 using screwdriver #19 and tighten fully.








6	x8	8	x8	19	x1
					
D3.5x14mm					

Step 9





1. Use screw #21 to attach the hinges #12 to door panel (J&K), tighten screws #21 with screwdriver #19.
2. Use screw #6 to attach the hardware #4 to door panel (J&K), tighten screws #6 with screwdriver #19.
3. Use screw #7 to attach the handle #7 to door panel (J&K), tighten screws #7 with screwdriver #19.



7	x2	21	x8	12	x4	4	x2	6	x4
									
D4x30mm		D4x16mm		Large Bend				D3.5x14mm	


Step 10



Insert shelf pin #11 into the holes attach adjustable shelf F to pin #11



Step 11


1. Use screw #21 to attach door panel J to part C, tighten screws #21 with screwdriver #19.
2. Use screw #21 to attach door panel K to part D, tighten screws #21 with screwdriver #19.




21	x16	19	x1
			
D4x16mm			

Door Hinge Adjustment Instructions


Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm
mounting screw or via cam
adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!







Video for door adjustment

Hinge adjustment method





Step 12

Use screws #6 to attach part #16 with screwdriver #19 as picture shown




6	x4	16	x2	19	x1
					
D3.5x14mm					


Step 13

16	x2	15	x4	14	x4	19	x1
		 D4x30mm					

1. Install the anti-collapse device.
2. Mark the position on the wall, that corresponds to the location of part (#16) on the Side panel (C&D); Drill and insert the expandable screw (#14) by hammer.
3. Assemble the part (#16) to the wall. Align the hole in the part (#16) with the expandable screw (#14), use screw (#15) to attach it and tighten by screwdriver (#19)







NOT PROVIDED



Step 14

Let the plastic belt #17 pass through the both part #16 and pull tightly



WARRANTY

- We strive to offer quality products, and we also try our best to satisfy every customer who orders from us with products or services as needed.
- We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their orders such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
- Replacement parts by purchasing them from our company if they are available.
- For return, please check the return policy with the retailer or market place you bought from

Are you having difficulty

With assembly? Missing parts?
Please send an email with your order No.to
hello@hulalahome.com

Appreciate your purchasing from us.
Pop up your life by our furniture piece!