

ITEM NO. DKHN0066-1

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No <u>customerservice@hulalahome.com</u> For return, Please check the return policy with the retailer or MarketPlace you bought from.

Appreciated your purchasing from us. Pop up your life by our furniture piece!


MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or pol ish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.



PARTS LIST

(1



Check all parts according to parts and hardware list make sure all parts present before assembly as some small parts may come loose during transit. Place all parts on clean padded surface and line up according to sequence of assembly.

HARDWARE LIST

A	M6x15	В	4mm	С	M6x35	D		Ε	1/4*38	F	15*12	
					0		Ö		~ ®		N. N	
	12pcs		1pc		6pcs		3pcs		3pcs		46pcs	
G	7*36	Η	8*30	I	3.5*14	J	4*40	K	16″	L	M6*25	
				BUDE		<u>⊛=</u> >		<u>A</u>)		
	46pcs		8pcs		24pcs		12pcs		3pcs		6pcs	
M												
	A											
	6pcs											

SPARE EXTRA PARTS


A	M6x15	С	M6x35	F	15*12	G	7*36	Н	8*30		3.5*14
						62- 9				(MILL)	
	1pc 1pc			1pc	1	рс]	lpc	3pcs		
J	4 * 40	L	M6*25	Μ							
⊛⊐ >		(k)			A						
1pc		1	рс		1pc						

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

open and place all parts on a clean, no-marring surface.

STEP 1:


Ax12




Use bolt A and allen Key B to connect stretchers 3 and 4 with side frames 1&2. Make sure all parts sets leveled then fasten all bolts to secure.

STEP 2:


Ix24 Kx3




Use wood screw I and philips head screw driver to attach drawer slides K to end panel and partition 11&12&6&7.



Turn the center partition 6&7 upside down, use philips head screw driver to fasten bolt F on inserts of back panel 8, bottom panel 9&10, then insert the bolts G on back panel 8 through end holes of center partition 6&7, put on cam unit F and fasten to secure. Use philips head screw driver and wood screw J to attach bottom panel 9&10 to bottom edge of center partition 6&7.




Use philips head screw driver to fasten bolt G on inserts of end panel 11 & 12, back panel 8, then insert the bolts G on end panel 11 & 12 through end holes of bottom panel 9 & 10, put on cam unit F and fasten to secure.




Use philips head screw driver to fasten bolt G on inserts of table top 13, Insert all dowels H to holes on back side of table top 13 then insert the bolts G on table top 13 through end holes of end/back/bottom panels assembly (6&7&8&9&10&11&12), put on cam unit F and fasten to secure.

STEP 6:


Cx6





Use philips head screw driver and bolt C to attach the metal frame assembly to bottom of upper unit, make sure all edges align then fasten to secure.

STEP 7:




Use philips head screw driver to fasten bolt G on inserts of drawer front 15/16/17 and back 14, put on cam unit F and fasten to secure.

Insert drawer bottom through channel along lower edge of drawer front 15/16/17 and back 14, insert the bolts G on end of drawer front 15/16/17 and back 14 through end holes of drawer sides 18/19, put on cam unit F and fasten to secure. Use philips head screw driver, bolt L to attach drawer face 21 to assembled drawer box, make sure the drawer face align with drawer box then fasten to secure.

Use philips head screw driver, bolt and washer E to attach knob D to the drawer assembly, fasten to secure


STEP 8:



Pull out the drawer slides and carefully align the pin on drawer slides with the hole on drawer box then fix the clip to secure the drawer. Whenever drawer adjustment of drawers needed, please spin the pin on drawer slides to set it level.

STEP 9:

Mx6



Switch the button with hand to slightly adjust the height of drawer sides in order to sent the drawer leveled. Insert the plastic clip M through the slide to the hole on drawer sides.

