

# HULALA

---

## H O M E



### ITEM NO.1461 DRESSER

---


#### NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

---



# MAINTAINANCE AND WARNING

- .Keep furniture away from heat sources.
- .Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- .Do not place furniture under direct sunlight,material will possibly fade over time.
- .Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
- .Do not write on furniture that is not protectedby a padded barrier.
- .Not for commercial use,only for residential use.






Weight Limitation  
**100 LBS**

# EXPLOSIVE VIEW





Around 15 min


# 1461 PARTS LIST

|                                                                                   |    |                                                                                   |    |                                                                                    |    |
|-----------------------------------------------------------------------------------|----|-----------------------------------------------------------------------------------|----|------------------------------------------------------------------------------------|----|
| A                                                                                 | x1 | B                                                                                 | x4 | C                                                                                  | x1 |
|  |    |  |    |  |    |

# HARDWARE LIST (1461)

|                                                                                   |     |                                                                                   |     |                                                                                   |     |                                                                                    |    |
|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------|-----|------------------------------------------------------------------------------------|----|
| #1                                                                                | x16 | #2                                                                                | x16 | #3                                                                                | x16 | #4                                                                                 | x2 |
|  |     |  |     |  |     |  |    |
| ϕ1/4x13/16"                                                                       |     | ϕ1/4                                                                              |     | ϕ1/4                                                                              |     |                                                                                    |    |

# TOOL LIST (1461)


|                                                                                     |    |                                                                                     |    |
|-------------------------------------------------------------------------------------|----|-------------------------------------------------------------------------------------|----|
| #5                                                                                  | x1 | #6                                                                                  | x1 |
|  |    |  |    |
| M4                                                                                  |    | Not available                                                                       |    |


# ASSEMBLY INSTRUCTIONS

## STEP-1

Align Legs (B) to the Chest (A), then secure by using Bolts (1) with Washers (2,3), tighten with allen key(5).

Align Center Legs (C) to the Chest (A).



|                                                                                     |     |
|-------------------------------------------------------------------------------------|-----|
| #1                                                                                  | x16 |
|  |     |
| ø1/4x13/16"                                                                         |     |

|                                                                                     |     |
|-------------------------------------------------------------------------------------|-----|
| #2                                                                                  | x16 |
|  |     |
| ø1/4                                                                                |     |


|                                                                                     |     |
|-------------------------------------------------------------------------------------|-----|
| #3                                                                                  | x16 |
|  |     |
| ø1/4                                                                                |     |


|                                                                                      |    |
|--------------------------------------------------------------------------------------|----|
| #5                                                                                   | x1 |
|  |    |
| M4                                                                                   |    |


# ASSEMBLY INSTRUCTIONS


## STEP-2

Use the anti-tip hardware kit (4) to secure the cabinet to the wall. The installation method for the hardware is included in the anti-tip hardware package.




|                                                                                     |    |
|-------------------------------------------------------------------------------------|----|
| #4                                                                                  | x2 |
|  |    |

|                                                                                     |    |
|-------------------------------------------------------------------------------------|----|
| #6                                                                                  | x1 |
|  |    |
| Not available                                                                       |    |



Leveler



# WARRANTY

1. We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed.
2. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive.
3. Replacement parts by purchasing them with our company if they are available.

[customerservice@hulalahome.com](mailto:customerservice@hulalahome.com)

Are you having difficulty  
With assembly? Missing parts?  
Please send email with your order No to  
**[customerservice@hulalahome.com](mailto:customerservice@hulalahome.com)**  
For return, please check the return policy with  
the retailer or market place you bought from.

Appreciate your purchasing from us.  
Pop up your life by our furniture piece!