



EliteNest™

2-SEATER ASSEMBLY INSTRUCTIONS




Two Seaters without A/B




Two Seaters with A/B

2-Seater Parts List

A/B x1



F x1




G x1



I x2




H x1



L x1




M x2




SEATER ASSEMBLY INSTRUCTIONS


Recliner (Right)




Recliner (Left)



Arm Rest




Step 1



Note: If neither Console A nor B is included, the next seat can be connected directly in same way.



Step 2



Note: If neither Console A nor B is included, the next seat can be connected directly in same way.

Functions Introduction

Power Connect



Reclining

