



EliteNest™

3-SEATER ASSEMBLY INSTRUCTIONS




Three-Seater without A/B




Three-Seater with A/B

3-Seater Parts List

A/B x1




D x1



E x1



F x1




G x1



I x2




H x1



L x1






M x2






SEATER ASSEMBLY INSTRUCTIONS



Recliner (Right)




Recliner (Left)



Arm Rest




Step 2



Note: If neither Console A nor B is included, the next seat can be connected directly in same way.



Step 2



Note: If neither Console A nor B is included, the next seat can be connected directly in same way.

Functions Introduction

Power Connect



Reclining

