



ITEM NO. Z6BCGR0581


Thank you for purchasing the Bookcase.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At HULALA home we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great designs to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell. We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.

Exploded Diagram



















Requires 2 adults for assembly


















Around 40 min

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.










PARTS LIST

A x 1  Top Panel	B x 1  Upper Back Panel	C x 3  Upper Connecting Bar
D x 1  Upper Front Panel	E x 1  Upper Fixed Panel	F x 1  Back Panel
G x 1  Left Side Panel	H x 1  Right Side Panel	I x 1  Adjustable Shelf Panel
J x 1  Back Connecting Bar	K x 1  Middle Fixed Panel	L x 1  Adjustable Shelf Panel
M x 1  Bottom Panel	N x 4  Leg	O x 1  Left Door
P x 1  Right Door		

HARDWARE LIST

1 x 18  Wood Dowel Ø8x30mm	2 x 6  Bolt M7x38mm	3 x 5  Cam Bolt	4 x 5  Cam Lock
5 x 8  Bolt M6x55mm	6 x 8  Flat Washer	7 x 8  Spring Washer	8 x 8  Shelf Support
9 x 4  Hinge	10 x 8  Flat Head Screw Ø3.5x14mm	11 x 4  Flat Head Screw Ø3.5x12mm	12 x 2  Handle
13 x 1  LED Strip	14 x 1  Power Adapter	15 x 6  Plastic Wedge	16 x 6  Flat Head Screw Ø3.5x16mm
17 x 1  Allen Key	18 x 1  Screwdriver	19 x 2  Anti-tilting Hardware	20 x 2  Anchor

SPARE LIST


1 x 2  Wood Dowel Ø8x30mm	3 x 1  Big Cam Bolt	4 x 1  Big Cam Lock	5 x 1  Bolt M6x55mm
6 x 1  Flat Washer	7 x 1  Spring Washer	8 x 1  Shelf Support	11 x 1  Flat Head Screw Ø3.5x12mm
16 x 1  Flat Head Screw Ø3.5x16mm			

Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, stop installing and contact your supplier immediately.


NOTE: Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.

NOTE: Should be assembled on soft surface to keep balance.


IF HAVE THIS ACCESSORY




It may be necessary to adjust the hinges so that the doors align. Use the instructions below as a guide.




To adjust the door vertically loosen the screw as shown and move up and down as needed.



To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.




To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.




Please fix other screws.


IF HAVE THIS ACCESSORY




QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.



CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.







Quickfit head should be in the centre of the cam lock when the two panels are joined.



Turn cam lock clockwise to tighten.


STEP 1


1		x 6
2		x 3
18		x 1



1. Insert wood dowel (1) into the corresponding hole of part (C).
2. Attach part (B) to parts (C) make sure all holes aligned with bolt (2) use screwdriver (18) to tighten it as show.



STEP 2


3		x 5
---	---	-----



Attach cam bolt (3) with screwdriver (18) to tighten as show.


STEP 3

1		x6
4		x3




1. Insert wood dowel (1) into the corresponding hole of part (C).
2. Attach part (D) to parts (C) make sure all holes aligned with cam lock (4) use screwdriver (18) to tighten it as show.

STEP 4





Attach part (A) to slots of parts (C&D) sure all slots aligned as show.


STEP 5



Insert the part(A) of rack installed in STEP2 into the slot of Part E and push it forward to sure that the Cam bolt is inserted into the hole of part (E).



STEP 6


2		x 3
4		x 2



- 1.Insert the Cam lock (4) to holes of the part (E) with screwdriver(18) tighten as shown.
- 2.Attach bolts(2) to holes of the part(E) with screwdriver(18) tighten .




STEP 7


1		x 2
17		x 1



Insert wood dowel (1) into the corresponding hole of part (K). make sure all holes aligned and use Allen key (17) to tighten it as show.


STEP 8


5		x 8
6		x 8
7		x 8



Install bolt (5) and connect it to part (N) through the hole of part (6/7&M) and tighten it with Allen key (17).


STEP 9

1		x 2
---	---	-----









Insert wood dowel (1) into the corresponding hole of part (G & H). make sure all holes aligned and use Allen key (17) to tighten it as show.

STEP 10



Open the back panel (F) and insert it into the slot of the parts (G/H/M) as shown.

STEP 11






Insert wood dowel (1) into the corresponding hole of part (G & H). make sure all holes aligned and use Allen key (17) to tighten it as show.




STEP 12



Step 2





Step 1



Install the LED strip along the indicated direction in the slot of the part and connect the port as show.




STEP 13

8		x 8
---	---	-----




Insert the shelf support (4) into the holes of side panel and put parts(I & L) ,As show.

STEP 14



15		x 6
16		x 6
19		x 2

Flat Head Screw
ø3.5x16mm




- 1.Attach parts(10) to body with screw (11) use screwdriver to tighten it as show.
- 2.Attach parts(19) use screwdriver to tighten as show. 3. Pull out the cable of the LED.

STEP 15



9		x 4
10		x 8

Flat Head Screw
Ø3.5x14mm




Attach part(6) to part(O/P) with screw (7) use screwdriver to tighten it as show.

STEP 16

11		x 4
12		x 2

Flat Head Screw
Ø3.5x12mm




1. Attach parts(O/P) to body use screwdriver to tighten it as show.



2. Attach part (12) to parts (O/P) with screw(11) use screwdriver to tighten it as show.



STEP 17

14		x 1
----	---	-----




STEP 18


19		x 2
20		x 2



1. Mark the position on the wall, and use an electric drill to make the hole.




2. The corresponding hole position on the wall, the anchor (20) is hammered in.



3. The alignment of the Anti tipping hardware with the hole of the anchor (20) is tightened with a screwdriver using screw (19).

STEP 19



MAINTAINANCE AND WARNING



- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.
- The maximum load is 100 LBS.

WARRANTY

We strive to offer high- quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No to customerservice@hulalahome.com

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!