


ITEM NO. Z6DKDZ0586


Thank you for purchasing this Writing desk.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At HULALA home we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great designs to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell. We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.


Exploded Diagram




PARTS LIST (Carton A)



PARTS LIST (Carton B)



HARDWARE LIST (Carton B)




Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, stop installing and contact your supplier immediately.


NOTE: Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed. NOTE: Should be assembled on soft surface to keep balance.

ASSEMBLY INSTRUCTION


STEP 1




Install L connect bracket (8) onto back of top panel (A) using bolt (1) and fully tighten the bolt with Allen key (6).




First insert wooden dowel (3) into left side panel (C), Then connect left side panel (C) to top panel (A).




Install L connect bracket (8) onto left side panel (C) using bolt (1) and fully tighten the bolt with Allen key(6).




Install turntable (7) onto small top panel (B) using bolt (2) and fully tighten the bolt with Allen key(5).



Connect turntable (7) to top panel (A) using bolt (2) tighten the bolt with Allen key(5).




Install L connect bracket (8) onto small top panel (B) using Bolt (1) and fully tighten the bolt with Allen key(6).




First insert wooden dowel (3) into right side panel (D), Then connect right side panel (D) to small top panel (B).


Install L connect bracket (8) onto right side panel (D) using bolt (1) and fully tighten the bolt with Allen key(6).




After open the drawer, remove the shelf.












Place turntable (7) onto body (E) using bolt (2), fully tighten the bolt with Allen key as shown.




Place the body (E) on the small top panel (B) as shown.





Connect turntable (7) to small top panel (B) using bolt (2), fully tighten the bolt with Allen key(5).






Use a screwdriver(9) to remove the round handle and install it in front as shown.







Insert the shelf support (4) and put shelf .

STEP 18





When you need to secure the table, engage the brake.



MAINTAINANCE AND WARNING



- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.
- The maximum load is 80 LBS.

WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing Parts? Please send email with your order No to customerservice@hulalahome.com

For return, please check the return policy with the retailer or market place you bought from . Appreciate Your Purchasing from us. Pop up your life by our furniture piece!