




## **ITEM NO. Z6DKDZ0710**

Thank you for purchasing this Standing desk.



Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At HULALA home we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great designs to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell. We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.

# Exploded Diagram



Z6DKDZ0710




## PARTS LIST (Carton A)

<b>A</b>	<b>x 1</b>	<b>C</b>	<b>x 1</b>
 Top Panel		 Clamp Block (Prepare for the installation of the monitoring bracket)	

## HARDWARE LIST (in Carton A)

<b>1</b>	<b>x 12+1</b>	<b>2</b>	<b>x 1</b>
 Bolt M6x12mm		 Allen Key 4#	

## PARTS LIST (Carton B)

<b>B</b>	<b>x 2</b>	
 Foot Box		


Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, stop installing and contact your supplier immediately.

# ASSEMBLY INSTRUCTION

## STEP 1




Note: The operation takes two adults to complete.



Place a layer of foam or packing paper or felt underneath.


## STEP 2



Put foot box into the bottom of table and carefully slide it to both sides respectively until it is completely aligned on both sides.


## STEP 3

1		x 4
2		x 1



Use the wrench (2) to tighten bolt (1) to approximately 100%.

## STEP 4




1. Pull the motor cable out through the holes of top panel (A).
2. Connect the power cord as shown in the diagram

Note:  
Please note that the connector here must not be incorrect.

## STEP 5

The wires need to be securely fastened with wire clips.




## STEP 6

Flip the products forward in order, as shown.





Note:  
The operation takes two adults to complete.



## STEP 7

 controller  
needs to be reset





 **Reset Operation:**

1. Press and hold the "▼" button for 5 seconds until "RST" appears on the display.
2. Press and hold the down "▼" button until you hear a "di" and the display shows the lowest height. During this process, the desk will rebound by about 10 mm. The controller will only function normally after the reset is complete.


1. Insert the power cable into the adapter and turn on the power supply.
2. Once the power is on, you'll need to restore the settings.

## STEP 8

1. Press the rise button to raise the tabletop.




For details, refer to the  
Controller Manual.



2. The doors on the foot box can be easily pushed open, and a second push will close it.
3. If the door does not open or close properly, you can twist it inward or outward as shown in the figure.


## STEP 9

1  x 8



After raising the desktop, lock all the Bolts from the bottom.

## STEP 10




**WARNING:**  
Do not place hands or objects  
on top to prevent injury or danger!

**CAUTION:**  
The sound you hear when activating the lifting function is  
normal and is caused by the high speed of the motor.

**WARNING:**  
1.The load of the lifting table must be less than 200 LBS!  
2.When raising or lowering the tabletop, ensure that the  
tabletop remains stationary and does not move!

---

## STEP 11




---

## Option

Component C (Clamp Block) can be used to assist in installing a monitor bracket.

Does not include the monitor bracket.



## MAINTAINANCE AND WARNING



- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.
- The maximum load is 200 LBS.

## WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No to [customerservice@hulalahome.com](mailto:customerservice@hulalahome.com)

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!