


ITEM NO.Z6DTJY0627

Thank you for purchasing the Dining Table.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product. At HULALA home we are committed to making great products possible. From our in-house Design Team, to our Buyers, we work together to bring great designs to life. Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell. We are all committed to designing and developing products to the highest industry standards. We hope you are happy with your product and welcome any feedback or comments you may have.




EXPLOSIVE VIEW

Z6DTJY0627 Dining Table




! IMPORTANT

Please follow the instruction manuals and use a pad to protect the product during your assembly.






Recommend 2 adults for quicker assembly.





Take 2 adults about 25 minutes to finish assembly.






Box: A PARTS LIST

| | | |
|--|---|---|
| A x 1  Table Top | B x 1  Leaf | C x 2  Mounting plate |
|--|---|---|

Box: B PARTS LIST

| | | |
|---|---|--|
| D x 2  Side panel | E x 2  Front / back panel | |
|---|---|--|






HARDWARE LIST (IN BOX A)




| | | |
|---|--|--|
| 1 x 28  Bolt Ø5/16"*1-3/4"L | 2 x 28  Spring Washer 5/16 | 3 x 28  Flat Washer 5/16 |
| 4 x 1  Allen Wrench | 5 x 8  Wood Dowel Ø10 x 30mm | |

Please confirm that you have received box A and box B then begin the assembly.

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.




STEP 1


| | | |
|---|---|------|
| 1 |  | x 12 |
| 2 |  | x 12 |
| 3 |  | x 12 |
| 4 |  | x 1 |
| 5 |  | x 8 |



First, insert the wooden Dowel (5) into the pre-drilled hole in Side panel (D) as shown in the figure. Then align the pre-drilled holes on Front /Back panel (E) with the exposed tenon of Side panel (D), and assemble them together.




STEP 2


| | | |
|---|---|-----|
| 1 |  | x 8 |
| 2 |  | x 8 |
| 3 |  | x 8 |



Then use hardware Bolt(1), spring washers (2), and flat washers (3) to fix together. (Tighten the screw to 100%)




STEP 3


| | | |
|---|---|-----|
| 1 |  | x 8 |
| 2 |  | x 8 |
| 3 |  | x 8 |



Use hardware Bolt(1), spring washers (2), and flat washers (3) to connect connecting plate Mounting plate(C) ,and base (D)and(C) together.



STEP 4

| | | |
|---|---|-----|
| 1 |  | x 8 |
| 2 |  | x 8 |
| 3 |  | x 8 |




Use hardware Bolt(1), spring washers (2), and flat washers (3) to connect Mounting plate(C) ,and Table Top (A).

STEP 5





Turn the table over and proceed to the next step of assembly.

STEP 6





Open the locking clips at the bottom of the tabletop and spread the panels out to both sides.

STEP 7



Follow the instructions to place the middle plate into the open position between the two side plates. Fold the sides of the tabletop towards the center and lock the locking clips.

STEP 8



Note: Adjust the leg levelers as needed.

Adjust the leveling feet at the bottom of the legs to keep them on the same level.

MAINTAINANCE AND WARNING



- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.
- The maximum load is 400 LBS.

WARRANTY

We strive to offer high quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

Are you having difficulty with assembly? Missing parts? Please send email with your order No to customerservice@hulalahome.com

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!